





### Octava Remote Control Hex Code



Button	Hex	Dec
A	0x12	18
B	0x1E	30
C	0x01	01
D	0x03	03
+	0x1A	26
-	0x02	02
1	0x04	04
2	0x05	05
3	0x06	06
4	0x07	07
5	0x08	08
*	0x09	09
ON/OFF	0x0C	12
AUX	0x0D	13
LED	0x0E	14

Octava Remote Control Hex Code



Button	Hex	Dec	Button	Hex	Dec
ON_OFF	0x00	00	E1	0x18	24
LED	0x03	03	E2	0x19	25
A1	0x04	04	E3	0x1A	26
A2	0x05	05	E4	0x1B	27
A3	0x06	06	F1	0x1C	28
A4	0x07	07	F2	0x1D	29
B1	0x08	08	F3	0x1E	30
B2	0x09	09	F4	0x1F	31
B3	0x0A	10	G1	0x40	64
B4	0x0B	11	G2	0x41	65
C1	0x0C	12	G3	0x42	66
C2	0x0D	13	G4	0x43	67
C3	0x0E	14	H1	0x44	68
C4	0x0F	15	H2	0x45	69
D1	0x10	16	H3	0x46	70
D2	0x11	17	H4	0x47	71
D3	0x12	18	AUX	0x48	72
D4	0x13	19	STAR	0x4B	75